


## Changing & Selecting


Treatment recording must be OFF  
(turn off Master Switch)

### Select a new field




Note: This action clears data in selected memory location


### Suspend an uncompleted field




### Finish an uncompleted field



### Archive a completed field



### Change swath width (single section boom)



## Virtual Wrench™

You must have sufficient cell phone coverage on mojoRTK console to connect to Virtual Wrench™

### Connect to Virtual Wrench



### Upgrade software



### Request support



### Disconnect from Virtual Wrench



For support visit:  
[www.mojoRTK.com](http://www.mojoRTK.com)

AUS + NZ 1800 836 656  
US 1-877-800-6656  
EU 0800 756 9665

- when it has to be right

**Leica**  
Geosystems

Leica **iNEX**  
Mapping & Guidance Display

## Quick Reference Guide

### Main Menu



VIEW menu allows the map display properties to be changed



FIELD menu allows fields to be started and saved



GUIDE menu provides different guidance formations




SETUP menu allows the user to customise configurations



RECORDS menu allows the user to view historical information

### Main Screen




Part No: 1-1338  
Revision: A  
Date: Mar 09

- when it has to be right


**Leica**  
Geosystems

## Using Guidance


### AB Parallel guidance




### A+ Heading guidance



### Adaptive guidance



### Pivot guidance




### RePLAY guidance




### Stop guidance



### Change guidance type



### Save Guidelines



### Load Guidelines



## Viewing

### Zoom in/out



### North up/ Heads up



### GPS details



### Day/night mode




night mode

OFF




## AutoSPRAY (optional upgrade)

### Turn AutoSPRAY ON/OFF




### View AutoSPRAY information



Toggle (touch) status bar until visible:



### Override AutoSPRAY



## AutoSTEER (optional upgrade)


### Turn AutoSTEER ON/OFF



### Engage AutoSTEER



### Disengage AutoSTEER



- when it has to be right

**Leica**  
Geosystems